

## RECEIVE #1

<b>1</b> UP 100HZ	<b>2</b> SCAN UP MEDIUM	<b>3</b> SCAN UP FAST
<b>4</b> DOWN 100HZ	<b>5</b> SCAN DOWN MEDIUM	<b>6</b> SCAN DOWN FAST
<b>7</b> <sup>+2</sup> MEMORY SET	<b>8</b> UP 500HZ	<b>9</b> <sup>+2</sup> MEMORY RECALL
<b>*</b> <sup>+8</sup> SET VFOA PLAY VFOA	<b>0</b> DOWN 500HZ STOP	<b>#</b> <sup>+1</sup> MENU SELECT PLAY VFOB

## ANTENNA #2

<b>1</b> ANTENNA 1	<b>2</b> ANTENNA 2	<b>3</b> TUNER IN
<b>4</b> <sup>+3</sup> SWITCH TO ANT1+ROTATE	<b>5</b> <sup>+3</sup> SWITCH TO ANT2+ROTATE	<b>6</b> TUNER OUT
<b>7</b> AUX 1 ON	<b>8</b> AUX 1 OFF	<b>9</b> TUNE ANTENNA
<b>*</b> <sup>+8</sup> SET VFOA PLAY VFOA	<b>0</b> STOP ROTATION	<b>#</b> <sup>+1</sup> MENU SELECT PLAY VFOB

## FILTER #3

<b>1</b> ANTENUATOR	<b>2</b> PRE AMP	<b>3</b> NOISE BLANKER
<b>4</b> NOISE REDUCTION	<b>5</b> AUTO NOTCH	<b>6</b> BEAT CANCEL
<b>7</b>	<b>8</b>	<b>9</b> <sup>+1</sup> MODE SELECT
<b>*</b> <sup>+8</sup> SET VFOA PLAY VFOA	<b>0</b> FUNCTION OFF ALL OFF	<b>#</b> <sup>+1</sup> MENU SELECT PLAY VFOB

## TRANSMIT #4

<b>1</b> TRANSMIT	<b>2</b> SPEECH COMP. ON	<b>3</b> VOX ON
<b>4</b> TONE ON	<b>5</b> SPLIT ON	<b>6</b> AMP ON
<b>7</b> <sup>+2</sup> SET TONE FREQ (SEE CHART)	<b>8</b> <sup>+1</sup> SHIFT: S,+,-	<b>9</b> <sup>+2</sup> RECALL MEMORY
<b>*</b> <sup>+8</sup> SET VFOA PLAY VFOA	<b>0</b> <sup>+1</sup> RECEIVE FUNCTION OFF	<b>#</b> <sup>+1</sup> MENU SELECT PLAY VFOB

## SETTINGS #5

<b>1</b> GENERAL	<b>2</b> ADVANCED	<b>3</b> EXTRA
<b>4</b> PASSWORD	<b>5</b> RESET RADIO	<b>6</b>
<b>7</b> <sup>+1</sup> SET # OF RINGS	<b>8</b> VOICE VOLUME UP	<b>9</b>
<b>*</b> <sup>+8</sup> SET VFOA PLAY VFOA	<b>0</b> VOICE VOLUME DOWN	<b>#</b> <sup>+1</sup> MENU SELECT PLAY VFOB

## AUXILLARY #6

<b>1</b> ON	<b>2</b> <sup>+1</sup> AUX 2	<b>3</b> <sup>+1</sup> AUX 3
<b>4</b> <sup>+1</sup> AUX 4	<b>5</b> <sup>+1</sup> AUX 5	<b>6</b> <sup>+1</sup> AUX 6
<b>7</b> <sup>+1</sup> AUX 7	<b>8</b> <sup>+1</sup> AUX 8	<b>9</b> <sup>+1</sup> AUX 9
<b>*</b> <sup>+1</sup> SET VFOA PLAY VFOA	<b>0</b> <sup>+1</sup> OFF	<b>#</b> <sup>+1</sup> MENU SELECT PLAY VFOB